

USB 2.0 CARD READER

5 SLOTS FOR ALL MEMORY CARDS

USER GUIDE


Transfer your digital files from different flash memory cards quickly and easily!

USB 2.0 High Speed Card Reader series provide you the easiest, fastest way to access your storage cards. By integrating the latest USB 2.0 technology, we will bring you the extremely fast speed up to 480Mbps/Sec. You can easily write/read files and images to the storage cards.

The Card reader supports all major memory card types including:

CF I, CF II, Microdrive, SD, miniSD, MMC(4.0), RS-MMC(4.0), MS, MS MagicGate, MS PRO, MS Pro MagicGate, MS Duo, MS Duo MagicGate, MS Pro Duo, MS Pro Duo MagicGate, MS Pro Ultra II, MS ROM, MS Select, MicroSD.

Illustration for card insertion.



Features:

- Hi-Speed USB 2.0 backwards compatible with all USB 1.1 ports
- All five memory slots are active, which allows you to copy data between the different memory cards at the same time
- Separate reader and docking station for quick desktop/laptop connectivity
- USB Mass Storage Class Devices
- Max Speed will be up to 480Mbit/sec
- Plug & play and Hot Swapping
- Windows 98/98SE/2000/XP and Mac OS 9.x/Mac OS X

Specifications:

Interface	USB 2.0
OS	Win98SE / ME / 2000 / XP & Mac OS 8.6+
Data Transfer	USB 2.0 High Speed
Power Input	By USB port

Minimum System Requirements:

Windows

Pentium class PC with USB support
Windows 98SE, 2000, ME, XP
CD-ROM drive
USB 2.0 port required from Hi-Speed transfer.

Macintosh

Macintosh computer with USB support
Mac OS 9.1.x and 9.2.x, OS X v10.1.2+
CD-ROM drive
USB 2.0 port required from Hi-Speed transfer

Installation for Windows 98/SE/2000

1. Insert the driver CD into the CD-ROM drive.
2. Click the CD-ROM drive icon.
3. Follow the step of "Install Wizard" to install the "USB Card Reader Driver".
4. Click "Yes" to reboot the system.
5. Plug your card reader into USB port and Windows 98SE will detect it automatically.
 - a. The pop-up window "Find new Hardware" will come out.
 - b. Wait for Windows 98SE to configure the card reader. When the installation (of the card reader driver) is successful, this pop-up window will disappear automatically.
 - c. Open "my computer", you'll see removable drives installed in your computer, then the installation is completed.
 - d. The installation is completed.

Installation for Windows ME/XP.

This card reader is a driver-free device for Windows ME. You don't have to install any driver and can plug into USB port directly.

Windows ME will detect and install all the associated files automatically.

Uninstall Driver:


1. Please run the setup process again to uninstall the driver.
2. Follow the on-screen instruction to complete the process.
3. System would ask you to restart the computer, please choose "Yes, I want to restart my computer now" to restart your PC, the uninstall will be done.

Remove Device:

For Windows 98/98SE Users

- Before you remove your flash cards or reader, please wait for "Access LED" on reader stops blinking to prevent data loss.

For Windows ME/2000/XP Users

- Please double-click the icon  on the system tray. A dialog box will appear.

Double-click the Generic USB Storage Device to remove the device or cards for preventing from data loss.